## 1. Supplied Accessories

2. Installation

Normal Installation using Mounting Bracket

2) Drill holes and fix mounting bracket on the location.

5) Connect the power cable to the transceiver cable.


sure of the polarity of the battery first and connect the cable.

Your transceiver is supplied with a full range of accessories to help you get started and virtually benefit from all the features straight away.

#### 840evo Transceiver 1 unit Microphone with cord 1 unit Power cable 1 unit Radio mounting bracket 1 unit Radio mounting thumb screw with rubber washer Mounting screw with washer (for transceiver bracket) 3 pieces Mounting screw with washer (for microphone bracket) 2 nieces Microphone mounting bracket 1 unit DIN front plate 1 unit DIN body plate 1 unit

# **4W MOBILE CB TRANSCEIVER**





## INSTRUCTION MANUAL



- 2) Channel/Backlight/Dimmer

-3) LCD Display 4) Volume/Power -

P/N 820-C110-D06

– 5) Microphone

Jack

- 6) AM,FM/Menu

/Last Channel Recall

- 7) Mic Gain

## www.midtkom.dk

4. Transceiver Controls and Functions

danita

12) Squelch/DSS ----

11) Emergency Channel/Lock - - - -

10) Echo/PA - - - -

8) VOX/Compander - - - - - - -

9) Scan/Dual Watch -----

#### 1) Front Speaker

the fuse box of the car)

operate the transceiver.

#### 2) Channel / Backliting / Dimmer Selector

Turn right or left, and this allows you to select the channel one by one. Momentary press this selector, and the channel display will blink. Then turn right or left, which allow you to change the backlight color. The second press will lead you to dimmer change mode.

3) Connect the antenna cable plug to the standard receptacle on the transceiver, which is marked

4) Connect the power cable directly to the vehicle battery or fuse box of the car. Be careful to make

(Red: Positive Pole(+), Black: Negative Pole(-). The same colors are shown on the battery and in

6) Mount the microphone bracket on one side of the transceiver, or near it using two screws

7) Connect the microphone to the transceiver's microphone receptacle. Now you are ready to

1) Put the mounting bracket on the proper location where you are going to install

#### 3) LCD Display

4) Volume / Power Knob

#### 5) Microphone Jack

6) AM.FM / Menu Button


Short press to change AM / FM.

Long press to access Menu mode. Use the Channel/Backlight knob to select the setting. On the Microphone, press center key (VOX button) to access Menu mode. Use Up/Down key to

#### <MENU>


Display	Functions	Settings		
bn	Band Selection	See next band chart		
bE	Bluetooth Selection	On, Off		
nb	Noise Blanker	On, Off		
6P	Beep Tone	On, Off		
Fo	Time-out Timer	1-99 sec., Off		
AF	Attenuation	On, Off		

#### Installing into Audio Compartment



- 1) Install the Din-Body plate into the audio compartment (center fascia) of your vehicle. (Use the ready made locking flaps.)
- 2) Set the transceiver in the Din-Front plate, and insert the transceiver in the Din-Body plate.
- 3) Fix the screws through the transceiver, Din-Front plate and Din-Body plate.

#### Installing an Antenna



- 1) Place the antenna as high as possible
- 2) The longer the antenna is, normally the better is the performance of the transceiver.
- 3) Try to mount the antenna in the centre of the surface that you select.
- 4) Make sure that you have a solid metal-to-metal ground connection.
- 5) Be careful not to damage the cable during the installation.

Warning: Never try the operation of your transceiver before connecting a proper antenna in order not to cause any damage.

### <BAND Chart>

Setting	Display	Settings
EC	EC	Europe 40ch. FM 4W
EU		Europe 40ch. AM/FM 4W
D	D.	Germany 80ch. FM 4W, 40ch. AM 4W
12	ហ៊	Italy 34ch. AM/FM 4W
I	•	Italy 40ch. AM/FM 4W
UE(EU/UK)	UE	UK 40ch. FM 4W (British Frequencies) + CEPT 40ch. FM 4W(EC)
UK	H	UK 40ch. FM 4W (British Frequencies)
PL	PL	Poland 40ch. AM/FM 4W (Polish Frequencies : 5KHz)
F	ш	France 40ch. FM 4W, 40ch AM 4W
E	E	Spain 40ch. AM/FM 4W

#### 7) Mic Gain / LCR Button

Short press to change the Mic Gain level to high (H), mid (M) and low (L) with the display indication. Long press to go to the Last Channel you have used.

#### 8) VOX / Compander Button

Short press to activate the VOX. Using the Mic gain the sensitivity can be adjusted. Long press to activate the embedded Compander function.

#### 9) Scan / Dual Watch Button

Short press to activate Scan function


Long press to activate Dual Watch function. The current channel is the home channel and the secondary channel can be selected by the channel selection knob. The display blinks DW icon.

#### 10) Echo / PA Button

Short press to activate Echo voice.

Long press to use PA system. Please check your PA speaker is connected. (option)

#### 3. LCD Display



### 11) 9/19 / Lock Button

Short press to go to the emergency channel (9 or 19). Long press to lock keypad. The volume, squelch and 9/19 buttons are still working.

## 12) Squelch / DSS Knob

Manual Adjustment: Turn this knob counter-clockwise until you hear the background noise and then turn the knob a little clockwise until the noise disappears. In this way, you get the best receive

DSS: In FM mode turn the knob counter-clockwise until you hear the click. The squelch level of your transceiver is dynamically adjusted.

#### 13) Antenna Connector

14) PA Jack


15) Mic & PTT Jack

16) External Speaker Jack


17) Power 13.2V DC

18) Bluetooth Dongle Connection

#### 5. Microphone



- 1) Up Button
- 2) Down Button
- 3) Mute / VOX Button Mute: Momentary press the button to make mute the speaker. VOX : Press long then VOX will be activated.
- 4) PTT Button
- 5) 6 Pin Microphone Connector



#### 6. How to operate the Transceiver

- 1) Make sure the microphone is connected to the microphone iack.
- 2) Make sure the power cable is connected properly.
- 3) Make sure the antenna is connected to the antenna receptacle.
- 4) It is better to put the squelch control knob turned fully counter-clockwise.
- 5) Turn on the transceiver and control the volume level.
- 6) Adjust the squelch control knob to the optimum level.
- 7) Select your desired channel.
- 8) To transmit, press the PTT button and speak to the microphone.
- 9) Release the PTT button to receive.

#### 7. Trouble shooting

If you experience problems with your 840evo transceiver, first check the power supply source. Poor connection of the power supply source can cause problems such as no transmission, no reception or poor reception, and weak or no sound. Ensure that the microphone and antenna are also well

If this does not solve the problem, reset your transceiver as follows.

- 2) Pressing "9/19" button and turn on the transceiver.

This will reset the transceiver, so all the memories are erased and the parameters return to the initial factory setting. This should fix most problems.

In case of further difficulty, please consult your dealer or visit our website.

#### 8. CE Declaration

CE versions of the 840evo which display the CE symbol on the product label, Comply with the essential requirements of the Radio Equipment Directive (RED) 2014/53/EU.



This warning symbol indicates that this equipment operates in non-harmonized frequency bands and/or maybe subject to licensing conditions in the country of use.

Be sure to check that you have the correct version of this radio or the correct programming of this radio, to comply with your national licensing requirements.

This unit can be used without license and charges in; Austria, Belgium, Bulgaria, Cyprus, Czech, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland, and U.K.

### 9. Safety Requirement

The power cable is for 13.2 / 24V DC only. Be sure the transceiver is off before connection the leads of the power cable to the power supply. It is important to observe the polarity even if the unit is protected against the accidental inversion :

- \* Red : Positive pole (+)
- \* Black : Negative pole (-)

The same colors are present on the battery and in the fuse box of the car.

The unit must be wired for the negative ground only. To avoid damage, do not operate your CB radio without connecting a proper antenna

#### << Declaration of Conformity >>

We, TTI Tech Co., Ltd. (#1312 361 Simindaero Dongan-gu Anyang-si Gyeonggi-do Korea) declare on our sole responsibility that this equipment complies with the essential requirements of the Radio Equipment Directive (RED) 2014/53/EU, and that any applicable Essential Test Suite measurements have been performed.

Kind of equipment: MOBILE CB TRANSCEIVER

Type-designation: 840evo

Version (where applicable)

This complicance is based on conformity with the following standards, specifications or

EN 62311:2008 V2.2.0 FN 301 489-13 V1.2.1 EN 60950-1:2006+A11:2009 +A1:2010+A12:2011+A2:2013

(

N. Y. Kim Director

documents:

Korea, Sept. 10, 2021

Signature

#### << Declaration of Identical Product >>

We, TTI Tech Co., Ltd. (#1312 361 Simindaero Dongan-gu Anyang-si Gyeonggi-do Korea) declare that we are the original manufacturer of the CB transceiver brand TTI and model TCB-1100, and we hereby declare that it is totally identical electronically and mechanically to the CB transceiver brand "Danita" and model "840evo".

The mentioned two CB transceiver are different only by their brand name and model name marking for their commercial reasons only.

Korea, Sept. 10, 2021

N. Y. Kim Director

Signature

## 10. Specifications

	-	<b></b>		
	Channel	40 (See the frequency band chart)		
GENERAL	Frequency Range	26.56 MHz ~ 28 MHz		
	Operating mode	F3E (FM), A3E (AM)		
	Frequency Control	PLL Synthersizer		
	Frequency Tolerance	0.002%		
	Operating Temperature Range	-10 to +55 ℃		
	Microphone	Plug-in Type		
	Input Voltage	13.2 / 24V DC ± 15%		
	Size	190 (W) x 175 (L) x 58 (H)		
	Weight	892.7 g		
	Antenna Connector	SO-239 type		
Т	Power Output	Duty cycle 10% 4 Watts @ 13.8V DC		
TRANSM-TTER	Modulation	AM: from 85% to 95% FM: 1.8KHz $\pm$ 0.2KHz		
M	Frequency Response	300Hz to 3000Hz		
ł	Output Impedance	50ohms, Unbalanced		
T F	Harmonic Suppression	Less than -36dBm		
R	Current Drain	AM Full Mod. 1.6A Max.		
	Receiving System	Dual conversion superhterodyne		
	IF Frequencies	Double conversion 1st 10.695MHz/2nd 455KHz		
RECE-VER	Sensitivity	$0.7\mu N$ for $10$ dB(S+N)/N in AM Mode $0.7\mu N$ for 20dB SINAD in FM Mode		
	Audio Output Power	2W @ 8ohm		
	Audio Distortion	Less than 8% @ 1KHz		
	Image Rejection	More than 60dB		
	Adjacent Channel Rejection	More than 60dB		
	Conducted Spurious	Less than -57dBm		
	Frequency Response	300Hz to 2500Hz		
	Built-in Speaker	8+++ohms, Round		
	Squelch	Adjustable; Threshold less than 1 $\mu$ V DSS; Less than 2 $\mu$ V		
Specification is subject to change without prior notice.				

#### 11. Restrictions on the use

						<b>_</b>
Country			Band			Use restrictions and other comments
BELGIUM		EU	F		EC	40 Ch - 4W FM - Individual licence is required
SWITZERLAND		EU	۲			40 Ch - 4W AM - Individual licence is required
DENMARK,NORWAY LUXEMBOURG,CZECH					EC	40 Ch - 4W FM - Free use
FINLAND,PORTUGAL		EU	F		EC	40 Ch - 4W FM - Free use
FRANCE, NETHERLANDS						40 Ch - 4W AM - Free use
GERMANY	_					80 Ch - 4W FM - Individual licence is required
	D					40 Ch - 4W AM - Individual licence is required
		EU				40 Ch - 4W AM - Use ch 4-15 only
					EC	40 Ch - 4W FM - Free use
	D2					12 Ch - 4W AM - Individual licence is required
	fx A	llowe	d: fro	m 26	5.960	to 27.410 MHz "BAPT 222 ZV 104"
GREECE	Е	EU	F	1	EC	40 Ch - 4W FM - Free use
						40 Ch - 4W AM - Free use
	T/R	20-0	12			
IRELAND	Е	EU	F	1	EC	40 Ch - 4W FM - Free use
						40 Ch - 4W AM - Free use
						RELESS TELEGRAPHY ACT, 1926 (SECTIONS) IS' BAND (CB) RADIOS) ORDER, 1998
ITALY	Е	EU I	F	1	EC	40 Ch - 4W FM - General authorization is required
						40 Ch - 4W AM - General authorization is required
						34 Ch - 4W FM
				12		34 Ch - 4W AM(ERP) *AM mode allowed on ch1-23 only
	PNF	issu	ed on	DM	08.0	7.02 NOTES 49 A-B-C-D-E-G
SPAIN	Е	EU	_		EC	40 Ch - 4W FM - Individual licence is required
			F			40 Ch - 4W FM - Individual licence is required
	Art.	57 -	Law	11/19	998 c	lated 24th April
SWEDEN		EU	F		EC	40 Ch - 4W FM - Free use
						40 Ch - 4W AM - Individual licence is required
UK	UK	K EU			EC	40 Ch - 4W FM - Free use
						40 Ch - 4W AM - Free use
POLAND	PL	EU			EC	40 Ch - 4W FM / AM - Free use