

Quick guide 3M™ PELTOR™ WS™ ALERT™ XPV

Power On & Off

Hold the ON/OFF button for 2 s.



"Power on"

Hold the ON/OFF button for 2 s.



"Power off"

Connect cell phone

When the headset starts for the first time it automatically starts in Bluetooth pairing mode.




"Bluetooth pairing on"



Activate Bluetooth and search for new device. Pairing complete confirms with "Connected"

Select ambient listening Profile



"Profile"

Push ON/OFF button until the guide voice confirms "Profile"



Push + or - to choose profile A, B, C or Off.

Volume Bluetooth® connected cell phone




"Phone volume"

Push ON/OFF button until the guide voice confirms "Phone volume"



Push + or - to adjust the Phone volume

Streaming volume Bluetooth® connected cell phone



"Streaming volume"

Push ON/OFF button until the guide voice confirms "streaming volume"



Push + or - to adjust the Streaming volume

Activate Push-To-Listen (PTL)



Double click ON/OFF button to activate "Push-To-Listen"



Push any button once to deactivate "Push-To-Listen"

Menu navigation



"Menu"


Press + & - button at the same time to enter the menu.



Push menu button several times to go through the menu options.

Quick guide 3M™ PELTOR™ WS™ ALERT™ XPV

Answer a phone call




"Incoming call"

Push once to answer the phone call

Place the microphone close to your mouth approximately 3-5 mm.

Push once to end the phone call

Play, Pause & Skip music streaming



Push once for Play and Pause x1

Double click to skip forward x2


Multifunction button



Use M button to operate.

Download the App and configure the multifunction button of your choice.

Reset to factory default




"Menu"

Press + & - button the same time to enter the menu.

"Factory reset"

Push On/Off button several times until the guide voice confirms "factory reset".



"Hold + button to confirm"

Hold + button for two seconds to confirm.

2 sec

"Reset to factory default"

"Power off"

More info, see user instruction